Exterior Bollard LED

START FROM HERE

• Make sure **POWER** is **COMPLETELY OFF** at the fuse box
• Have your fixture installed by a qualified licensed electrician
• Prepare everything in a clear area
• Wear gloves at all time during this installation
• Read instructions carefully before you start assembly
• Keep this installation sheet for future reference

Technical Support: 1-855-855-8926

Please Note:
• This Kuzco LED fixtures come with pre-wired LED module(s)
• Unless instructed, Do Not touch any part of the LED module(s) as any unnecessary contact with the module could cause permanent damage
• 120-277V input
• Non-Dimming

1. Remove fixture from its original package

2. Provide means to bring supply wiring to bollard in accordance with local code before pouring concrete

3. Secure anchor bolts **(1c)** to mounting guide plate **(1e)** with hex nuts and washers provided **(1d)** before concrete cures

4. After concrete is set, replace mounting guide plate **(1e)** with mounting base **(2b)**, adjust mounting base to desired orientation and then secure with hex nuts and washers **(1d)**

5. Pull conduit through base plate to make proper electrical connection (black to hot "L", white to neutral "N", ground to "GND") with wire nuts **(1b)** provided in hardware package, tie access wires to avoid contact with ground

6. Place Base cover **(1a)** over mounting base **(2b)**, secure with set screws **(2a)** with Allen key provided.

2a.
1a.
1d.
2b.
1b.

Illustration 2

1c.
1d.
1e

KUZCO