
## **ASSEMBLY INSTRUCTIONS**



## **Hadley Medium Pendant**

Item # CS 5301

WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.

WARNING\*\*\*SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION. INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY

DAMAGE OR OBVIOUS DEFECT. DO NOT INSTALL. IF THERE IS ANY

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED. NOTE: CAREFULLY UNPACK EACH PIECE IN TOP LAYER OF PACKING PRIOR TO REMOVING. RETAIN ALL PACKING MATERIAL UNTIL INSPECTION AND INSTALLATION ARE FINAL.

\_\_\_\_\_

- 1. Carefully remove all parts from the box.
- 2. Thread the tube (H) to the fixture body (I), then thread the tube (G) to the tube (H).
- 3. Attach the rope band (L) to the bottom of the metal shade (K).
- 4. Hang the metal shade (K) to the chain (J).
- Affix the crossbar (B) with ceiing loop (C) onto the outlet box and secure with mounting screws (D).
- 6. Attach the canopy (E) to the ceiling loop (C) and secure with lock collar (F).
- 7. Hang the fixture body to the ceiling loop (C).
- 8. Loosen the lock collar (F) and let canopy (E) slip down the tube carefully.
- Connect the fixture Ground (bare) wire with the ground wire from the outlet box using wire nut (A). If your house does not have ground wire, then attach this wire to the green grounding screw inside of the outlet box.

IT IS IMPERATIVE THAT THIS FIXTURE BE GROUNDED.

- Connect the fixture Neutral (ribbed, no markings) wire with the neutral wire from the outlet box using wire nut (A).
- 11. Connect the fixture Hot (smooth edge,markings) wire with the hot wire from the outlet box using wire nut (A).

DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.

- 12. Tuck these wire connections neatly into the outlet box to secure.
- 13. Attach canopy (E) to the crossbar (B) and secure with lock collar (F).
- 14. Insert bulbs (not included) into the sockets.
- 15. Installation is complete, turn on power at fuse or circuit breaker.

\*\*\*Clean with a dry, soft cloth only. Use no harsh abrasives or chemical agents.

VISUAL COMFORT & CO. EST. 1987